

## Web page for PTZ cameras Upgrade Procedure.

Following four webimg files have different PTZ protocol list. Depends on your PTZ device, you need to select only one “webimg” file from four files and upload it onto RTOS version of FlexWATCH server.

**\* Notice!**

**If no PTZ camera needed, simply select the first one “Webimg\_Dome\_A”**

- Select one of the zipped webimg file from below list
- Unzip the “webimg” you chose, and you will see a file named as “webimg”.

### Webimg\_Dome\_A Group (Factory Default)

NO	Company	Model
1	Seyeon	SRX-500/SPT-102
2	Seyeon	FSD-301
3	Seyeon	FSD-230
4	Pelco-D	Spectra Dome Series
5	Pelco-P	Spectra Dome Series
6	Honeywell	HSDN-251(H)
7	SAMSUNG	SCC641
8	SANTEC	Santec Dome
9	ELMO	ELDOME
10	VICON	SURVEYOR-1000(2000)
11	SONY	EVI-D30

### Webimg\_Dome\_B Group

NO	Company	Model
1	Seyeon	SRX-500/SPT-102
2	Seyeon	FSD-301
3	Seyeon	FSD-230
4	Pelco-D	Spectra Dome Series
5	Pelco-P	Spectra Dome Series
6	CANON	VC-C4
7	American Dynamics	AD DELTA DOME SERIES
8	KALATEL	CYBER DOME (KTA-xxxx)
9	Panasonic	WV-CS854
10	SAMSUNG TECHWIN	SPD1600
11	RNK	RNK-DOME

### Webimg\_Receiver\_A

NO	Company	Model
1	Seyeon	SRX-500/SPT-102
2	Seyeon	FSD-301
3	Seyeon	FSD-230
4	Pelco-D	Spectra Dome Series
5	Pelco-P	Spectra Dome Series
6	SAMSUNG Techwin	SRX-100B
7	SAMSUNG Electronics	MRX-1000
8	VICON	V-1311RB
9	Honeywell	HRX-2000
10	SungJin	SJ-xxxx
11	DongYang Electronics	DY-xxxx

### Webimg\_Receiver\_B

NO	Company	Model
1	Seyeon	SRX-500/SPT-102
2	Seyeon	FSD-301
3	Seyeon	FSD-230
4	Pelco-D	Spectra Dome Series
5	Pelco-P	Spectra Dome Series
6	ERNITEC	BDR-510
7	EVERTECH	ET-50
8	FINE	CRR-1600I
9	Inter-M	VSD-64
10	KODICOM	KRE-301
11		

- 1) When you turn on the system, and meet the prompt, and then type "ls" on the console!( hyperterminal window )  
You will see files described as below.

```
$ ls ↵
```

```
BITMAP.SYS      FLIST.SYS      SysConfig      flexwatch
```

- 2) Clear previous web page of FlexWATCH,

```
$ rm -r flexwatch ↵
```

- 3) Upload the new web file (**webimg.bin**) to FlexWATCH™ using FTP

- If you do not have that kind of utility, just type ftp command on Dos Command Window and follow the procedure described as below

- Please make sure that "webimg.bin" file is reside in home directory of C: drive to upload in the file using Dos command.

ex. C:\> ftp [10.10.10.10](http://10.10.10.10) ↵  
and type login id as " root", and proper password ( default password is also "root" )

```
ftp> binary ↵  
ftp> hash ↵  
ftp> put webimg.bin ↵  
ftp> bye ↵
```

- check if there is error occurred during the transfer

- 4) Type the command "**chgwebimg**". Then just wait for completing the command. (It takes about 10 sec)

```
$> chgwebimg ↵
```

- 5) Just wait for completing the update, and then the FlexWATCH will reboot automatically and the new Web page will be working on it.

- 6) Connect FlexWATCH by using Web browser, check if Web Server 's Page and applet etc is working well.

### ● After upgrade:

- After update system firmware ver from 2.2/2.3 to 3.0, you must finish below steps:

- 1) Login to the system through telnet or HyperTerminal.
- 2) Input 'clearcfg' command through console/telnet.
- 3) Get into configuration mode (type "config" and hit 'enter key').
- 4) Input "@" command.
- 5) Input "reset" command to reboot the FlexWATCH system.
- 6) Assign an IP address to FlexWATCH system.
- 7) Make sure to save configuration and reboot the system.

### \* Notice!

After upgrade to ver 3.0, then you can easily upgrade the latest firmware ver through Admin menu on web-browser.